

Showerline Tile-Over Tray



Suggested installation products to use.

These products have been laboratory tested.

IMPORTANT : TRAY MUST BE THOROUGHLY SANDED PRIOR TO APPLYING ANY PRODUCTS TO ENSURE CORRECT ADHESION

For adhering tray to substrate

- Sikaflex – 11FC
- Ardex RA88
- Dunlop Builders Bond
- Selleys Proseries
- Selleys 3 in 1
- Mapeflex PU45

For surface priming

- Aqua Blok moisture seal
- Ardex WPM300 + Broadcast Sand
- Ardex Abapoxy + Broadcast Sand
- Ardex P9 Single Part Primer
- Gripset Betta Prime All
- Davco Ultraprime
- Dunlop Primer & Additive

For waterproofing

- Betta Rapid Dry Waterproofer Membrane
- Sikalastic-560
- Ardex WPM 155 Rapid Waterproofing

For tile adhesion

- Prohesive Ultrapro (also known as) MCB A100
- Ardex WA100
- Ardex Abaflex X77 +/- E90
- Ardex Abaflex X18 +/- E90
- Ardex STS8 + E90
- Dunlop Tile-All
- Mapei Kerapoxy 410
- Davco Flexible CTA Pre-mixed

For expansion joints

- Ardex CA20P
- Mapei Mapeflex PU45

For sealing over expansion joints

- Gripset/Betta peel & seal tape
- Ardex waterproofing detail tape